

## ADJ MIRAGE Q6 PAK - DMX TRAITS

### 4-Channel Mode

CHANNEL	DMX VALUES	DESCRIPTION
1	000 - 255	<b>Red</b> , 0-100%
2	000 - 255	<b>Green</b> , 0-100%
3	000 - 255	<b>Blue</b> , 0-100%
4	000 - 255	<b>Amber</b> , 0-100%

### 6-Channel Mode

CHANNEL	DMX VALUES	DESCRIPTION
1	000 - 255	<b>Red</b> , 0-100%
2	000 - 255	<b>Green</b> , 0-100%
3	000 - 255	<b>Blue</b> , 0-100%
4	000 - 255	<b>Amber</b> , 0-100%
5		<b>Strobe</b>
	000 - 031	LEDs Off
	032 - 063	LEDs On
	064 - 095	Strobe effect, slow to fast
	096 - 127	LEDs On
	128 - 159	Pulse, effect in sequence
	160 - 191	LEDs On
	192 - 223	Random strobe effect, slow to fast
	224 - 255	LEDs On
6	000 - 255	<b>Dimmer Intensity</b> , 0-100%

## ADJ MIRAGE Q6 PAK - DMX TRAITS

### 7-Channel Mode

CHANNEL	DMX VALUES	DESCRIPTION
1	000 - 255	<b>Red</b> , 0-100%
2	000 - 255	<b>Green</b> , 0-100%
3	000 - 255	<b>Blue</b> , 0-100%
4	000 - 255	<b>Amber</b> , 0-100%
5		<b>Strobe</b>
	000 - 031	LEDs Off
	032 - 063	LEDs On
	064 - 095	Strobe effect, slow to fast
	096 - 127	LEDs On
	128 - 159	Pulse, effect in sequence
	160 - 191	LEDs On
	192 - 223	Random strobe effect, slow to fast
	224 - 255	LEDs On
6	000 - 255	<b>Dimmer Intensity</b> , 0-100%
7		<b>Dim Mode</b>
	000 - 020	Standard
	021 - 040	Stage
	041 - 060	TV
	061 - 080	Architectural
	081 - 100	Theatre
	101 - 120	Stage 2
	121 - 140	Dim Speed, fast to slow (0.1s - 10.0s)
	141 - 255	Default

## ADJ MIRAGE Q6 PAK - DMX TRAITS

### 8-Channel Mode

CHANNEL	DMX VALUES	DESCRIPTION
1	000 - 255	<b>Red</b> , 0-100%
2	000 - 255	<b>Red Fine</b>
3	000 - 255	<b>Green</b> , 0-100%
4	000 - 255	<b>Green Fine</b>
5	000 - 255	<b>Blue</b> , 0-100%
6	000 - 255	<b>Blue Fine</b>
7	000 - 255	<b>Amber</b> , 0-100%
8	000 - 255	<b>Amber Fine</b>

### 9A-Channel Mode

CHANNEL	DMX VALUES	DESCRIPTION
1	000 - 255	<b>Red</b> , 0-100%
2	000 - 255	<b>Green</b> , 0-100%
3	000 - 255	<b>Blue</b> , 0-100%
4	000 - 255	<b>Amber</b> , 0-100%
5		<b>Strobe</b>
	000 - 031	LEDs Off
	032 - 063	LEDs On
	064 - 095	Strobe effect, slow to fast
	096 - 127	LEDs On
	128 - 159	Pulse, effect in sequence
	160 - 191	LEDs On
	192 - 223	Random strobe effect, slow to fast
	224 - 255	LEDs On
6	000 - 255	<b>Dimmer Intensity</b> , 0-100%
7		<b>Auto Programs</b>
	000 - 010	Off
	011 - 026	Auto Program 1
	027 - 043	Auto Program 2
	044 - 060	Auto Program 3
	061 - 076	Auto Program 4

CONTINUED ON NEXT PAGE

## ADJ MIRAGE Q6 PAK - DMX TRAITS

### 9A-Channel Mode (cont'd)

CHANNEL	DMX VALUES	DESCRIPTION
7		<b>Auto Programs</b> (cont'd)
	077 - 093	Auto Program 5
	094 - 110	Auto Program 6
	111 - 126	Auto Program 7
	127 - 143	Auto Program 8
	144 - 160	Auto Program 9
	161 - 176	Auto Program 10
	177 - 193	Auto Program 11
	194 - 210	Auto Program 12
	211 - 226	Auto Program 13
	227 - 255	No Function
8	000 - 255	<b>Auto Program Speed</b> , slow to fast
9	000 - 255	<b>Auto Program Fade</b> , least to most

### 9B-Channel Mode

CHANNEL	DMX VALUES	DESCRIPTION
1	000 - 255	<b>Red</b> , 0-100%
2	000 - 255	<b>Green</b> , 0-100%
3	000 - 255	<b>Blue</b> , 0-100%
4	000 - 255	<b>Amber</b> , 0-100%
5	000 - 255	<b>Color Macros</b> , see <b>Color Macros</b> section
6	000 - 255	<b>Color Temperature</b> , 2400K-9900K, see <b>Color Temperature</b> section
7		<b>Strobe</b>
	000 - 031	LEDs Off
	032 - 063	LEDs On
	064 - 095	Strobe effect, slow to fast
	096 - 127	LEDs On
	128 - 159	Pulse, effect in sequences
	160 - 191	LEDs On
	192 - 223	Random strobe effect, slow to fast
	224 - 255	LEDs On

CONTINUED ON NEXT PAGE

## ADJ MIRAGE Q6 PAK - DMX TRAITS

### 9B-Channel Mode (cont'd)

CHANNEL	DMX VALUES	DESCRIPTION
8	000 - 255	<b>Dimmer Intensity</b> , 0-100%
9	000 - 255	<b>Dimmer Fine</b>

### 10-Channel Mode

CHANNEL	DMX VALUES	DESCRIPTION
1	000 - 255	<b>Red</b> , 0-100%
2	000 - 255	<b>Green</b> , 0-100%
3	000 - 255	<b>Blue</b> , 0-100%
4	000 - 255	<b>Amber</b> , 0-100%
5	000 - 255	<b>Color Temperature</b> , 2400K-9900K, see <b>Color Temperature</b> section
6		<b>Strobe</b>
	000 - 031	LEDs Off
	032 - 063	LEDs On
	064 - 095	Strobe effect, slow to fast
	096 - 127	LEDs On
	128 - 159	Pulse, effect in sequences
	160 - 191	LEDs On
	192 - 223	Random strobe effect, slow to fast
	224 - 255	LEDs On
7	000 - 255	<b>Dimmer Intensity</b> , 0-100%
8	000 - 255	<b>Dimmer Fine</b>
9		<b>Dim Curves</b>
	000 - 020	Linear
	021 - 040	Square
	041 - 060	Inv. Squa
	061 - 080	S. Curve
	081 - 255	No Function
10		<b>Refresh Rates</b>
	000 - 015	Default
	016 - 030	900 Hz
	031 - 045	1000 Hz

CONTINUED ON NEXT PAGE

## ADJ MIRAGE Q6 PAK - DMX TRAITS

### 10-Channel Mode (cont'd)

CHANNEL	DMX VALUES	DESCRIPTION
10		<b>Refresh Rates</b> (cont'd)
	046 - 060	1100 Hz
	061 - 075	1200 Hz
	076 - 090	1300 Hz
	091 - 105	1400 Hz
	106 - 120	1500 Hz
	121 - 135	2500 Hz
	136 - 150	4000 Hz
	151 - 165	5000 Hz
	166 - 180	10,000 Hz
	181 - 195	15,000 Hz
	196 - 210	20,000 Hz
	211 - 225	25,000 Hz
	226 - 255	No Function

### 11-Channel Mode

CHANNEL	DMX VALUES	DESCRIPTION
1	000 - 255	<b>Red</b> , 0-100%
2	000 - 255	<b>Green</b> , 0-100%
3	000 - 255	<b>Blue</b> , 0-100%
4	000 - 255	<b>Amber</b> , 0-100%
5	000 - 255	<b>Color Macros</b> , see <b>Colors Macros</b> section
6	000 - 255	<b>Color Temperature</b> , 2400K-9900K, see <b>Color Temperature</b> section
7		<b>Strobe</b>
	000 - 031	LEDs Off
	032 - 063	LEDs On
	064 - 095	Strobe effect, slow to fast
	096 - 127	LEDs On
	128 - 159	Pulse, effect in sequences
	160 - 191	LEDs On
	192 - 223	Random strobe effect, slow to fast
	224 - 255	LEDs On
CONTINUED ON NEXT PAGE		

## ADJ MIRAGE Q6 PAK - DMX TRAITS

### 11-Channel Mode (cont'd)

CHANNEL	DMX VALUES	DESCRIPTION
8	000 - 255	<b>Dimmer Intensity</b> , 0-100%
9	000 - 255	<b>Dimmer Fine</b>
10		<b>Dim Curves</b>
	000 - 020	Linear
	021 - 040	Square
	041 - 060	Inv. Squa
	061 - 080	S. Curve
	081 - 255	No Function
11		<b>Refresh Rate</b>
	000 - 015	Default
	016 - 030	900 Hz
	031 - 045	1000 Hz
	046 - 060	1100 Hz
	061 - 075	1200 Hz
	076 - 090	1300 Hz
	091 - 105	1400 Hz
	106 - 120	1500 Hz
	121 - 135	2500 Hz
	136 - 150	4000 Hz
	151 - 165	5000 Hz
	166 - 180	10,000 Hz
	181 - 195	15,000 Hz
	196 - 210	20,000 Hz
211 - 225	25,000 Hz	
226 - 255	No Function	

## ADJ MIRAGE Q6 PAK - DMX TRAITS

### 12-Channel Mode

CHANNEL	DMX VALUES	DESCRIPTION
1	000 - 255	<b>Red</b> , 0-100%
2	000 - 255	<b>Green</b> , 0-100%
3	000 - 255	<b>Blue</b> , 0-100%
4	000 - 255	<b>Amber</b> , 0-100%
5	000 - 255	<b>Color Macros</b> , see <b>Colors Macros</b> section
6	000 - 255	<b>Color Temperature</b> , 2400K-9900K, see <b>Color Temperature</b> section
7		<b>Strobe</b>
	000 - 031	LEDs Off
	032 - 063	LEDs On
	064 - 095	Strobe effect, slow to fast
	096 - 127	LEDs On
	128 - 159	Pulse, effect in sequences
	160 - 191	LEDs On
	192 - 223	Random strobe effect, slow to fast
	224 - 255	LEDs On
8	000 - 255	<b>Dimmer Intensity</b> , 0-100%
9	000 - 255	<b>Dimmer Fine</b>
10		<b>Dim Mode</b>
	000 - 020	Standard
	021 - 040	Stage
	041 - 060	TV
	061 - 080	Architectural
	081 - 100	Theatre
	101 - 120	Stage 2
	121 - 140	Dim Speed, fast to slow (0.1s - 10.0s)
	141 - 255	Default

CONTINUED ON NEXT PAGE



## ADJ MIRAGE Q6 PAK - DMX TRAITS

### 12-Channel Mode (cont'd)

CHANNEL	DMX VALUES	DESCRIPTION
11		<b><i>Dim Curves</i></b>
	000 - 020	Linear
	021 - 040	Square
	041 - 060	Inv. Squa
	061 - 080	S. Curve
	081 - 255	No Function
12		<b><i>Refresh Rate</i></b>
	000 - 015	Default
	016 - 030	900 Hz
	031 - 045	1000 Hz
	046 - 060	1100 Hz
	061 - 075	1200 Hz
	076 - 090	1300 Hz
	091 - 105	1400 Hz
	106 - 120	1500 Hz
	121 - 135	2500 Hz
	136 - 150	4000 Hz
	151 - 165	5000 Hz
	166 - 180	10,000 Hz
	181 - 195	15,000 Hz
	196 - 210	20,000 Hz
	211 - 225	25,000 Hz
226 - 255	No Function	

## ADJ MIRAGE Q6 PAK - DMX TRAITS

### 15-Channel Mode

CHANNEL	DMX VALUES	DESCRIPTION
1	000 - 255	<b>Red</b> , 0-100%
2	000 - 255	<b>Green</b> , 0-100%
3	000 - 255	<b>Blue</b> , 0-100%
4	000 - 255	<b>Amber</b> , 0-100%
5	000 - 255	<b>Color Macros</b> , see <b>Colors Macros</b> section
6	000 - 255	<b>Color Temperature</b> , 2400K-9900K, see <b>Color Temperature</b> section
7		<b>Strobe</b>
	000 - 031	LEDs Off
	032 - 063	LEDs On
	064 - 095	Strobe effect, slow to fast
	096 - 127	LEDs On
	128 - 159	Pulse, effect in sequences
	160 - 191	LEDs On
	192 - 223	Random strobe effect, slow to fast
	224 - 255	LEDs On
8	000 - 255	<b>Dimmer Intensity</b> , 0-100%
9	000 - 255	<b>Dimmer Fine</b>
10		<b>Auto Programs</b>
	000 - 010	Off
	011 - 026	Auto Program 1
	027 - 043	Auto Program 2
	044 - 060	Auto Program 3
	061 - 076	Auto Program 4
	077 - 093	Auto Program 5
	094 - 110	Auto Program 6
	111 - 126	Auto Program 7
	127 - 143	Auto Program 8
	144 - 160	Auto Program 9
	161 - 176	Auto Program 10
177 - 193	Auto Program 11	

CONTINUED ON NEXT PAGE

## ADJ MIRAGE Q6 PAK - DMX TRAITS

### 15-Channel Mode (cont'd)

CHANNEL	DMX VALUES	DESCRIPTION
10		<b>Auto Programs</b> (cont'd)
	194 - 210	Auto Program 12
	211 - 226	Auto Program 13
	227 - 255	No Function
11	000 - 255	<b>Auto Programs Speed</b> , slow to fast
12	000 - 255	<b>Auto Programs Fade</b> , least to most
13		<b>Dim Mode</b>
	000 - 020	Standard
	021 - 040	Stage
	041 - 060	TV
	061 - 080	Architectural
	081 - 100	Theatre
	101 - 120	Stage 2
	121 - 140	Dim Speed, fast to slow (0.1s - 10.0s)
	141 - 255	Default
14		<b>Dim Curves</b>
	000 - 020	Linear
	021 - 040	Square
	041 - 060	Inv. Squa
	061 - 080	S. Curve
	081 - 255	No Function
15		<b>Refresh Rate</b>
	000 - 015	Default
	016 - 030	900 Hz
	031 - 045	1000 Hz
	046 - 060	1100 Hz
	061 - 075	1200 Hz
	076 - 090	1300 Hz
	091 - 105	1400 Hz
	106 - 120	1500 Hz
121 - 135	2500 Hz	
CONTINUED ON NEXT PAGE		

## ADJ MIRAGE Q6 PAK - DMX TRAITS

### 15-Channel Mode (cont'd)

CHANNEL	DMX VALUES	DESCRIPTION
15		<b>Refresh Rate</b> (cont'd)
	136 - 150	4000 Hz
	151 - 165	5000 Hz
	166 - 180	10,000 Hz
	181 - 195	15,000 Hz
	196 - 210	20,000 Hz
	211 - 225	25,000 Hz
	226 - 255	No Function

### 18-Channel Mode

CHANNEL	DMX VALUES	DESCRIPTION
1	000 - 255	<b>Red</b> , 0-100%
2	000 - 255	<b>Red Fine</b>
3	000 - 255	<b>Green</b> , 0-100%
4	000 - 255	<b>Green Fine</b>
5	000 - 255	<b>Blue</b> , 0-100%
6	000 - 255	<b>Blue Fine</b>
7	000 - 255	<b>Amber</b> , 0-100%
8	000 - 255	<b>Amber Fine</b>
9	000 - 255	<b>Color Macros</b> , see <b>Color Macros</b> section
10	000 - 255	<b>Color Temperature</b> , 2400K-9900K, see <b>Color Temperature</b> section
11		<b>Strobe</b>
	000 - 031	LEDs Off
	032 - 063	LEDs On
	064 - 095	Strobe effect, slow to fast
	096 - 127	LEDs On
	128 - 159	Pulse, effect in sequence
	160 - 191	LEDs On
	192 - 223	Random strobe effect, slow to fast
	224 - 255	LEDs On
12	000 - 255	<b>Dimmer Intensity</b> , 0-100%

CONTINUED ON NEXT PAGE

## ADJ MIRAGE Q6 PAK - DMX TRAITS

### 18-Channel Mode (cont'd)

CHANNEL	DMX VALUES	DESCRIPTION
13		<b><i>Auto Programs</i></b>
	000 - 010	Off
	011 - 026	Auto Program 1
	027 - 043	Auto Program 2
	044 - 060	Auto Program 3
	061 - 076	Auto Program 4
	077 - 093	Auto Program 5
	094 - 110	Auto Program 6
	111 - 126	Auto Program 7
	127 - 143	Auto Program 8
	144 - 160	Auto Program 9
	161 - 176	Auto Program 10
	177 - 193	Auto Program 11
	194 - 210	Auto Program 12
	211 - 226	Auto Program 13
	227 - 255	No Function
14	000 - 255	<b><i>Auto Programs Speed</i></b> , slow to fast
15	000 - 255	<b><i>Auto Programs Fade</i></b> , least to most
16		<b><i>Dim Mode</i></b>
	000 - 020	Standard
	021 - 040	Stage
	041 - 060	TV
	061 - 080	Architectural
	081 - 100	Theatre
	101 - 120	Stage 2
	121 - 140	Dim Speed, fast to slow (0.1s - 10.0s)
	141 - 255	Default
CONTINUED ON NEXT PAGE		

## ADJ MIRAGE Q6 PAK - DMX TRAITS

### 18-Channel Mode (cont'd)

CHANNEL	DMX VALUES	DESCRIPTION
17		<b><i>Dim Curves</i></b>
	000 - 020	Linear
	021 - 040	Square
	041 - 060	Inv. Squa
	061 - 080	S. Curve
	081 - 255	No Function
18		<b><i>Refresh Rate</i></b>
	000 - 015	Default
	016 - 030	900 Hz
	031 - 045	1000 Hz
	046 - 060	1100 Hz
	061 - 075	1200 Hz
	076 - 090	1300 Hz
	091 - 105	1400 Hz
	106 - 120	1500 Hz
	121 - 135	2500 Hz
	136 - 150	4000 Hz
	151 - 165	5000 Hz
	166 - 180	10,000 Hz
	181 - 195	15,000 Hz
	196 - 210	20,000 Hz
	211 - 225	25,000 Hz
226 - 255	No Function	